

# **AIR TO WATER CHILLER HEAT PUMP**

---

## OPERATION&INSTRUCTION MANUAL

MODEL:

SWBB-19.0H-B-S

SWBB-89.0H-A-S

# CONTENTS

1.To our customers.....	1
2.Product Introducing.....	2
3.Specification .....	3
1)Technical data .....	3
2)Casing size .....	4
4.Usage .....	6
1)Controller introduction .....	6
2)Wire Controller Operation .....	7
3)Malfunction data .....	9
5.Wiring diagram .....	10
6.Installation instructions .....	12
1)Unit installation.....	12
2)Pipeline connecting .....	12
3)Project example .....	13
7.Running Test and operation .....	14
1)Preparatory work before the running test.....	14
2)Running test .....	15
3)Normal operation .....	15
8.Maintenance .....	16

# 1.To our customers

---

**Dear Sir:**

In order to use this machine safely, please read this INSTRUCTION MANUAL carefully before using and installation. Heat pump water heater is a professional machine, it may cause damage or hazard when wrong installed, it should be installed by a competent person in accordance with the relevant standards for the country of use.

**WARNING:**

***ELECTRICAL POWER MUST BE SWITCHED OFF  
BEFORE STARTING ANY WORK ON JUNCTION BOXES***

- 1.Before installing the heat pump, please ensure that the electrical supply corresponds to the specification indicated on the unit s rating label before proceeding with the connection in accordance with the wiring diagram supplied. Please check carefully on the rating label and the wiring diagrams that pasted on each heat pump unit.
- 2.The unit must be EARTHED to avoid any risks caused by insulation defects. It is forbidden to start any work on the electrical components without switching off the electrical supply to the unit. Electric leakage switch protection device **MUST** be installed.
- 3.It is forbidden to start any work on the electrical components if water or high humidity is present on the installation site.
- 4.When the unit is being connected, ensure that no impurities are introduced into the pipe work and the water circuits.
- 5.All maintenance or repairmen of the heat pump must be performed by competent technicians.
- 6.It could be hurtful when generated hot water reaches 50 °C , please mix with cold water before using.
7. To prevent any damage to the fan or any accidents, it is forbidden to put your fingers or any other objects into the air outlet. Kids or children should be kept away from the heat pump.
8. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 9.Children should be supervised to ensure that they do not play with the appliance.

## 2.Product Introducing

---

### Product Introducing

#### ⊙ **Safe and Reliable**

Unlike traditional electric water heater, heat pump water heater do not directly generate heat by electricity , it use less electricity to move heat from one place to another , electric circuit is separated from water circuit ,which is also not easy for electric shock, inflammable , explosion and poisoning ! Safer and more reliable!

#### ⊙ **Highly efficient & Energy saving**

Heat pump water heater absorb plenty of heat from free ambient air, and can supply same hot water volume as electric heater. Electricity consumption is only 1/4 compared to electric heater, very energy saving!

#### ⊙ **Environmental Friendly**

Heat pump not only use less electricity to get heat from ambient air , but are also able to combine using with solar equipment , will not cause pollution and no poison gas exhausting .

#### ⊙ **All Round The Year Hot Water**

Heat pump water heaters are not affected by seasonal climate, provide hot water all year round even in cloudy or rainy days!

#### ⊙ **Durable and long-lasting time**

Heat pump spare parts such as compressor and 4-way-valve are made by famous brand manufacturer , and casing panel is corrosion resistance, very durable and long-lasting time .

#### ⊙ **Convenient Installation**

Installation site for heat pump can be the roof, the garage , the kitchen, the storing room , the basement and so on, very convenient on installation .

#### ⊙ **Wide Application**

Heat pump water heaters are applicable for family, factory, school, hotel , hospital , and laundry ,etc. Wide application for different using request.

### 3. Specification

#### 1) Technical data


Unit Model		SWBB-19.5H-B/P-S	SWBB-89.0H-A-S
Cooling Capacity	kW	18.0	84.0
	BTU/h	62000	256000
Heating Capacity	kW	19.5	89.0
	BTU/h	67000	275000
cooling power Input	kW	5.4	28.0
Heating power Input	kW	5.4	24.0
Running current(cooling)	A	8.7	43.4×3
Running current(Heating)	A	8.7	35.0×3
Power Supply	V/Ph/Hz	380/3/50-60	380/3/50-60
Compressor quantity		1	4
Compressor style		Scroll	Scroll
Fan quantity		2	2
Fan power input	W	90*2	630*2
Fan rotate speed	RPM	850	830
Noise	dB(A)	58	64
Water Connection	inch	1	2
Water Flow Volume	m <sup>3</sup> /h	3.3	15.0
Water Pressure Drop	kPa	38	40
Unit Net dimensions(L/W/H)	mm	See the drawing of the units	
Unit shipping dimensions(L/W/H)	mm	See package label	
Net Weight	kg	See nameplate	
Shipping Weight	kg	See package label	

- Measurement conditions:  
Cooling: Outdoor air temp: 35 /24 , Outlet water temp:7 , Inlet water temp:12  
Heating: Outdoor air temp: 7 /6 , Outlet water temp:45 , Inlet water temp:40
- Pump power is same to pump motor power.  
(Above information just for your reference, Please subject to nameplate on the unit)


### 3.Specification

#### 2) Casing size (Measure: mm)

Applicable model: SWBB-19.0H-B-S




Applicable model: SWBB-89.0H-A-S



## 4.Usage

---

### 1). Controller introduction



### 2) Wire controller button definition

-  button  
---to turn on or turn off your heat pump.
-  button  
----up and down button to check or change setting.  
Press these two button at the same time for 3seconds, lock the keyboard.
-  button  
---use it for clock setting.
-  button  
----Press M for 3 seconds in standby status, could enter for Force Defrost.
-  button  
----Button for timming.Integrating with up and down button, to set the time for turning on or turning off the heat pump.

## 4. Usage

---

### 3) Parameters

Parameters	Definition	Range	Default	Remark
SET 0	Cold water set point temp	8-25°C	12°C	Can adjust
SET 1	Heat water set point temp	20-50°C	50°C	Can adjust
SET 2	Defrosting Cycle	30-90Min	40Min	Can adjust
SET 3	Temperature to enter to defrosting in heating mode	-30°C-0°C	-7°C	Can adjust
SET 4	Temperature to exit defrosting under heating mode	2-30°C	13°C	Can adjust
SET 5	Defrosting time	1-12Min	8Min	Can adjust
SET 7	System quantity	1 / 2	1	Can adjust
SET 8	Temp difference	2-15°C	5°C	Can adjust
SET 9	Second set point (maximum)	40-50°C	50°C	Can adjust
SET A	Second set point (minimum)	20-30°C	30°C	Can adjust
SET B	Water pump controlling mode: 0: water pump always on 1: water pump shut off after compressor stops for 30s.	0-1	0	Can adjust
1	Inlet water temperature	0~99°C		Tested data
2	Outlet water temperature	0~99°C		Tested data
3	Evaporator tube temperature of system 1	-35~80°C		Tested data
4	Evaporator tube temperature of system 2	-35~80°C		Tested data
7	Ambient temperature	-35~80°C		Tested data
8	Exhaust temp of system 1	0~125°C		Tested data
9	Exhaust temp of system 2	0~125°C		Tested data

## 4.Usage

---

### 4) Failure code and parameter tables

<b>Protect/Failure</b>	<b>Long-distance controller</b>	<b>Remark</b>
Heat ump in Stand-by mode		
Normal running		
Inlet water temperature sensor failure	Pp1	
Outlet water temperature sensor failure	PP2	
Coil temperature sensor 1 failure	PP3	
Ambient temperature sensor failure	PP5	
Coil temperature sensor 2 failure	PP6	
Winter anti-freezing protection I	PP7	
Winter anti-freezing protection II	PP7	
Gas suction side temperature sensor 2 failure	PP8	
Exhaust temp sensor 1 failure	PP9	
Exhaust temp sensor 2 failure	PP10	
Exhaust 1 high temp protection	PP 11	
Exhaust 2 high temp protection	PP 12	
System high pressure protection	EE1	
System low pressure protection	EE2	
Water flow switch failure	EE3	
Power source wrong/open phase	EE4	
Wire controller communication failure	EE8	
Defrosting	Defrost	

## 4.Usage

---

### 5) HOW TO SET WIFI FUNCTION

5.1 Long press wifi mould button for 3 seconds, (the black one on the mould PCB).

Reset the data of wifi function. When press for 3 seconds, the red night flash and power come on again.


5.2 Search WIFI “HF-LPB100”and connect it. (Strongly suggest to search wifi by computer).

Must be connect in 60seconds, otherwise you need to repeat step1 again.


5.3 Open website of “10.10.100.254” , input user name and password as below.

User name: admin      Password: admin

After that, you could find below interface.



5.4 Select work mode, change to STA mode. And then press Save. See below ref pic.



## 4.Usage

### 5) HOW TO SET WIFI FUNCTION

5.5 Then change the setting of “other setting”

Change Baud rate to 9600, and then save. (Please do not change other)

Serial Port Parameters Setting

Baud Rate	9600
Data Bit	8
Parity Bit	None
Stop Bit	1
CTSRTS	Disable

Save

Network Parameters setting

Protocol	TCP-Server
Port ID	8899
Server Address	10.10.100.254
TCP Time Out Setting	300

Save

5.6 Then select STA setting, press Scan, then press Save. See below refer pic.

Network Name (SSID)  
Note: case sensitive

HF-LPB100

Scan

Encryption Method

Disable

Obtain an IP address automatically

Enable

IP Address

0.0.0.0

Subnet Mask

0.0.0.0

Gateway Address

0.0.0.0

DNS Server Address


10.10.100.254

Save


# 4.Usage

## 5) HOW TO SET WIFI FUNCTION

5.7 Please choose the safety and reliable local area network which available. Then press OK to confirm.



5.8 Make sure the Encryption Method choose WPA2PSK, and Encryption Algorithm choose AES. Input the password of your local area network. Then press save.



## 4.Usage

### 5) HOW TO SET WIFI FUNCTION


5.9 Choose other setting again, make below setting as below, see refer pic.

Protocol : TCP-CLIENT.


Port ID : 8888.

Service ID: 115.29.137.48

Then press SAVE.



5.10 After finished all above steps, come to Restart interface, and press OK to confirm RESTART. See below pic.



## 4. Usage

---

### 5) HOW TO SET WIFI FUNCTION

5.11 Then with wifi, and open the website of 115.29.137.48, you can control the heat pump unit by Laptop or smart phone.


5.12 After finished all setting, green light on the mould PCB could be keep on. (That means it is success connect on wifi)

5.13 Open website 115.29.137.48, then could control the heat pump on line.

5.14 After wifi setting finished, Mac No. could be showed once power on. To control the unit on line, the Mac No. need to be used.

5.15 There are 12 numbers of Mac, and could be showed on each 2 numbers in order for a time, total 6 times. For example, Mac No. MAC123456789, firstly show M A, then C 1, and then 2 3, then 4 5. After then 6 7, at last 8 9.

Also it could show the Sequence No. on the place of clock, for example, M A is the Sequence 1 and Sequence 2, then 01, 02. See below pic for more details



## 4. Usage

### 6) Setting about S1,S2 & S3 switch

- S1 Switch---Second set point
- S2 Switch---Long distance demand for heating
- S3 Switch---Long distance demand for cooling

Please refer to the wiring diagram for the location of above S1, S2 & S3 switch.

1)Heat pump turns on when S2 or S3 switch has well connected.

While S2 or S3 has connected, suddenly press the off button on the LCD controller. Heat pump will stop for 3 minutes. However, heat pump continues to turn on if S2 or S3 still has been connected after 3 minutes.

2)The Timer function is out of validity either S2 or S3 switch has connected.

3)Heat pump turns off when S2 or S3 switch is disconnected. Meanwhile, need to use LCD controller to turn on /off the heat pump.

4)Second set point available when S1 switch has well connected.

At the same time, water temp set point setting decided by ambient temp, Parameter SET 9 and Parameter SET A. (Both C & D parameter could be adjusted).

Parameter SET 9 (maximum setting range 40-50 °C , default 50°C )

Parameter SET A (minimum setting range 20-30°C, default 30°C )

A. When ambient temp < 5°C, set point temp refer to the data of Parameter SET 9

B. When ambient temp >15°C, set point temp refer to the data of Parameter SET A


C When < ambient temp < 15°C, set point temp = Data of Parameter SET 9-(Data of parameter SET 9- data of parameter SET A)/(15-5)\*(ambient temp -5).

For example, when ambient temp is 18 deg c, Parameter SET 9 is 50 deg c, Parameter SET A is 30 deg c. Then set point temp=50-(50-30)/(15-5)\*(18-5)

5)When S1 disconnected, set point temp control by LCD controller.


(Refer to the setting of Parameter SET 9 & SET A (default setting 50° C & 30° C )

## 5. Wiring diagram



# 5. Wiring diagram

Applicable model: SWBB-89.0H-A-S




## 6. Installation instructions

### 1). Unit installation

#### (1). Installation location

##### Host unit

- ☐ Should be installed in a larger & well-ventilated place.
- ☐ Installation location should ensure unhindered access outlet (inlet & outlet shown as below).
- ☐ Install gutter or set up positions near the outfall, to facilitate the drainage.
- ☐ The installation base or bracket should be steady, to ensure the smooth operation of running units.
- ☐ Make sure the unit is vertical after installation, and no incline.
- ☐ Make sure not to install the host unit in the any conditioner of pollution, corrosive gases, sun and fallen leaves, etc.
- ☐ Installation location must not next to place of incensive , easy-explosion and fire .
- ☐ Installation must pay attention to the distance between the barriers shown in below picture (pay attention to arrow direction).



##### Water tank

- ☐ Water tanks should be placed where ambient temperature is above 0°C .
- ☐ Can be installed outdoors or the top of the building (based on the size of water tanks and the load-bearing capacity of the building and so on).
- ☐ Do not install water tanks in the pollution, corrosive gases place.

#### (2). Unit installation

- ☐ Units base can be installed as cement concrete structures, steel brackets can also be used, add the shockproof rubber pads , make the base surface flat.
- ☐ Units can be designed based on the working performance.  
(See Table of technical performance parameters)
- ☐ Unit should have drain or drainage inlets.
- ☐ Normally required to install in the place where setted cement concrete base.

## 6. Installation instructions

### 2). Pipeline connecting

#### Installation notes:


- ☐ Water drain pipes, overflow pipes should be installed next to the drainage inlets to facilitate drainage, vent valve should be installed on vent pipes.
- ☐ Repair valve should be installed in front of the electromagnetic valve on the pipeline system, which is convenient for future repair.
- ☐ User water pressure should less than 0.6 Mpa.
- ☐ All pipelines should choose metal pipe (such as stainless steel, with Lining Plastic and lining stainless steel and thin-walled copper pipe or, etc.). The use of plastic pipe (such as the PP-R, ABS, etc.) should consider the pipeline expansion between the host unit and water tanks.
- ☐ Water supply and pause valves may need to keep warm in the winter (according to the local winter temperature) to avoid the broken of water supply and pause valve.

#### Water system installation


- ☐ All the pipeline tubing should be matched as shown on the manual, and in accordance with national corresponding construction standards.
- ☐ Installation of water pipes should be straight and flat, pipeline collocation should be rational, ensure to minimize bending; reduce the resistance loss of the water system.
- ☐ Pipeline and connecting parts are not allowed a leakage phenomenon.
- ☐ After the installation of circulating pipe between tap water pipes, host unit and water tanks, should carry out water leakage testing, and eject the sewage to ensure the system's cleanness.
- ☐ If no water leakage, keep the hot water pipe warm.

### 3). Project example:

Application of heat pump water heater engineering systems have different forms. Here are two kinds of stand-alone group water heating system, only for your reference.



## 7. Running Test and operation



### Running Test and operation

#### 1). Preparatory work before the running test.

##### a) Inspection of heat pump water heater units:

- Check if the unit appearance and the pipeline system were damaged during transport.
- Check if there is air exist in the water pipes, if yes, should empty all the air inside by the manual exhaust valve and the exhaust valve on the water pumps.
- Check if the fan rotor interference the fan fixing board and fan protection net.

##### b) Check the electricity distribution System

- Check if the power supply same as shown on manual and rating label.
- Check if all the power supply and control wiring are all well connected, check if the wiring is connected as wiring diagram and reliability of earth wiring.

##### c) Check Pipeline system

- Check the pipeline system, make sure the water supply pipes, water return pipes, pressure gauges, thermometers, valves, water flow switch are safe and correct.
- Check if having opened all the valves that should be opened, and having closed all valves that should be closed.
- Check if all necessary attemperators are good.

# 7. Running Test and operation

---


## 2). Running test

This running test must be performed by professional staff!

- ☐ Overall test can be run if the entire system inspection is conformed to regulations.
- ☐ Connected to power, start the heat pump, host unit delays three minutes then auto-start. For three-phase power supply unit, first check whether the fans and pumps' rotary direction correct or not, if not, immediately shut down the power and adjust phase sequence. Measure the compressor operation current, and if any abnormal noise. Check whether the unit conform to the requirements, run for a period of time (general 3 days), after that, the unit can be used normally.

## 3). Normal operation

- ☐ Heating process: start - up - water pumps runs -water flow switch inspection --- Fan operation compressor operation (when the low water level cut off, water supply induction valve opens
- ☐ Operation Control:



- ☐ Water level control: When the low level switch disconnect, open the water supply induction valve to supply enough water, meanwhile stop the water supply pump. Open the water supply pump when high level switch closed, After high-level switch closed for two minutes, open water supply induction valve (at least 2 minutes).
- ☐ When water pump is on and the high level switch cut off, if water temperature  $<$  (set Temperature - 5 degrees), shut down water supply for tanks, If water tank temperature  $>$  (temperature - 2 degrees) then open the water supply induction valve, after high-level switch closed for two minutes stop the water supply induction valve. When water pumps stopped, whatever conditions, should supply enough water. (Water supply switch on at 2 minutes).
- ☐ For the first power-on boot, the circulating water pump, compressor, fan motor runs after low level switch closed.
- ☐ During the unit operation, circulating pump open. When the unit stopped, the circulating pump will be delayed 30 seconds then stop functioning.
- ☐ When water pumps open, meanwhile open water return induction valve, 10 minutes later, test the return water temperature, when the return water temperature  $>$  (water temperature - 5 degrees), the return water induction valve stops. If the return water temperature  $<$  (tank water temperature - 10 degrees), open the water return valve so that the water supply pump constantly store the hot water. When water supply pump closed, shut down the water return valve at the same time.
- ☐ For normal start-up, the 4-way valve cut off, only when defrosting, the unit will work in normal.

## 8. Maintenance

---

Heat pump water heater is a high automatic equipment, please perform regular inspection termly. If the unit can be long-term and efficiently maintenance, the operating reliability and service life will have an unexpected increase.

- 1.The extra water filters should be cleaned regularly to ensure clean water quality of the system, and to avoid damage caused by dirty water filter blocking.
- 2.Users should pay attention for usage and maintenance to below : all units' protection devices are set up before leaving factory, do not make any adjustment by yourself.
- 3.Frequently check the power supply and electrical wiring system is solid or not, whether electrical components are abnormally working, if yes, should timely maintenance and change for a new one.
- 4.Perform regular checks of the water supply system, check whether the tank safety valve, liquid level controller and exhaust devices work properly, so as to avoid air into the system, and reduce the water cycle volume, thus affect the heating function and operation reliability.
- 5.Check whether pumps and water valves are normal working or not, whether water tubing and water pipes connector are leakage or not.
- 6.The unit and around should remain clean, well-ventilated. Regularly clean (1-2 month)the side air heat exchanger to maintain a good effect of heat exchange.
- 7.Frequently check whether each part of the unit work normal or not, check whether there is oil on the pipeline joints and charging valve to ensure that no refrigerant leakage.
- 8.Do not piling up debris around the unit, so as not to block from air inlet and outlet, the unit around should be kept clean the dry, well-ventilated.
- 9.If the unit stops for a longer time, should drain all the water in the pipeline, cut off power supply, and sets the protective equipment.When re-run the unit, complete inspection is a must before reboot.
- 10.When unit failure, and the user can not resolve the problem, please call our Company in local maintenance department, in order to promptly send people for maintenance.
- 11.Host condenser cleaning.We propose to use 50℃-60℃, and 15% hot phosphoric acid for condenser cleaning, launch the circulating pump of the host unit for three hours' cleaning, finally rinse with water three times. (Propose to back up a 3-way connector when installing the pipeline, block one joint),in order to clear the connection pipe. Do not use corrosive cleaning fluid for condenser cleaning.
- 12.Water tanks need to remove theWater scale after some time (normally two months, according to the water quality of local place).

