

AQUAGEM®



TECHNICAL TRAINING



[CONTENT]

1. OPERATION

2. TROUBLE SHOOTING

3. DISASSEMBLY

AQUAGEM

Auto Inverter Mode (Flow rate)
Manual Inverter Mode (Running capacity)

Flow rate, Running capacity, Power consumption
reading

IW20 (0.75kW): 17.4 m³/h@8m

IW25 (1.05kW): 23.1 m³/h@8m

IW30 (1.4kW): 27.5 m³/h@8m

Digital input, RS485, WIFI



InverWarrior



OPERATION

AQUAGEN

CONTROL PANEL



Auto Inverter (Flow rate control)
Manual Inverter (Running capacity 30% ~ 100%)



Power consumption reading



Running capacity / Flow rate reading



One-click backwash





Timer Mode



INITIAL STAR UP

UNLOCK THE SCREEN

Hold  for more than 3s, all buttons on the screen will light up.

Press  to turn on the pump.



SELF PRIMING

Counting down from 1500s,
it will stop automatically when the system detects the pump is full of water.



RECHECK

Recheck for 30s to make sure the priming is successful.



INITIAL STAR UP

SELF LEARNING

Counting down from 180,
the system will redefine the adjustable flow range of Auto Inverter Mode
by detecting the pipeline pressure.






DEFAULT MODE

Manual Inverter Mode, 80%



MANUAL INVERTER MODE (DEFAULT)

RUNNING CAPACITY SETTING






- Press  to switch between Manual Inverter Mode and Auto Inverter Mode.
- Under Manual Inverter Mode, the “%” icon will light up.
- Press  and  to adjust the running capacity from 30% - 100%, each step by 5%, the parameter will be saved and the motor speed will be changed immediately.



AQUAGEN

AUTO INVERTER MODE









FLOW RATE SETTING

- Press  to switch between Manual Inverter Mode and Auto Inverter Mode.
- Under Manual Inverter Mode, the “flow unit” icon will light up
- Press  and  to adjust the flow rate,
(adjustable flow range as per the result of the self learning process)
the system will adjust the running capacity automatically to reach the set flow.
- The unit of flow rate could be changed to lpm, IMP gpm or US GPM
by pressing both   for 3 seconds



TIMER MODE

MAX. 4 TIMERS ON CONTROL PANEL

- Press  to enter timer mode.
- Press  and  to set local time,
press  to confirm the HOUR and MINUTE and enter the TIMER 1 setting.
- In each TIMER setting, press  and  to select the timer period and running capacity / flow rate,
(press  to switch between running capacity and flow rate), press  to confirm the setting.





TIMER MODE

NOTE







- When timer mode is activated, if the set time period contains the current time, the pump will start running according to the set running capacity or flow rate.
- If the set time period does not contain the current time, the timer number

1	2	3	4
---	---	---	---

 (or 1 or 2 or 3 or 4) that is about to start running will be displayed on the controller and flash, **88:88-88:88** will display the corresponding time period.
- All 4 time periods should be set in chronological order. Overlap setting of time will be considered as invalid, the pump will only run based on the previous valid setting.
- During timer setting, if you want to return to the previous setting, hold both  and  for 3 seconds

ONE-CLICK BACK WASH

BACK WASH TIME & CAPACITY


- Press  to enter the back wash or fast circulation mode, and set the time.
- Back wash time will be shown on the screen and flash, press  and  to adjust the time from 0 ~ 1500s (default 180s), back wash will begin after 3s without operation.
- Back wash capacity can be set in the “parameter setting”
(Under “OFF” mode, hold  and  for 3s to enter parameter setting, default 100%)
- Hold  for 3s can exit back wash mode during count down.



EXTERNAL CONTROL

PRIORITY: DIGITAL INPUT > RS485 > PANEL CONTROL



DI PRIORITY: PIN 4 > PIN3 > PIN2 > PIN1













Name↵	Color↵	Description↵
PIN 1↵	Red↵	Digital Input 4↵
PIN 2↵	Black↵	Digital Input 3↵
PIN 3↵	White↵	Digital Input 2↵
PIN 4↵	Grey↵	Digital Input 1↵
PIN 5↵	Yellow↵	Digital Ground↵
PIN 6↵	Green↵	RS485 A↵
PIN 7↵	Brown↵	RS485 B↵

PARAMETER SETTING

Under "OFF" mode,

hold  and  for 3s to enter parameter setting

Restore factory setting	Under off mode, hold both   for 3 seconds
Check the software version	Under off mode, hold both   for 3 seconds
Manual priming	Under on mode hold both   for 3 seconds
Enter parameter	Under off mode, hold both   for 3 seconds; If current address does no need to be adjusted, hold both   to next address

Parameter Address	Description	Default Setting	Setting Range
1	PIN3	100%	30~100%, by 5% increments
2	PIN2	80%	30~100%, by 5% increments
3	PIN1	40%	30~100%, by 5% increments
4	Backwash capacity	100%	80~100%, by 5% increments
5	Control mode of Analog Input	0	0: current control 1: Voltage control
6	Enable or disable the priming that occurs at each start	25	25:enables 0: disables



TROUBLE SHOOTING

AQUACAM

MECAHNICAL SEAL

WATER LEAKAGE FROM THE SEAL PLATE

- Stop the pump immediately
- Check if the water go into the motor, and if the seal plate or mechanical seal are damaged



Reference



Seal plate improvement

NOISE

NOISE FROM THE WET END OR MOTOR

- Shoot a video of the noise.
- Replace the wet end accessories or the motor



Wet end improvement



Bearing

ERROR CODE 002

OUTPUT OVER CURRENT


- Turn off the pump.
- Remove the controller and check if the green connection terminal turn black
- Replace with the new controller and connection terminal



| ERROR CODE 209

LOSS OF PRIME

- Record the power consumption during priming
- Check if the height between the water level and the pump is higher than 2m
- Check if suction side is too long or the pipeline system is too complex



Reference



Volute (1st generation)



Volute (2nd generation)

WARRANTY CLAIM

INFORMATION TO BE PROVIDED




- Serial No. on the nameplate.
- How long has the pump worked since the installation
- Problem description with photo / video
- Installation condition if needed
(indoor or outdoor/ height between the pump and the water level/ pipeline size & length etc.)

The background of the slide features a photograph of a swimming pool with a white lounge chair on the deck. In the distance, there are palm trees and a range of mountains under a hazy sky. The image is partially obscured by several overlapping geometric shapes: a large white triangle on the left, a smaller grey triangle in the center, and a large light-blue triangle on the right. The title text is positioned within the light-blue triangle.

DISASSEMBLY & ASSEMBLY

AQUACRAFT



REMOVE THE CONTROLLER

LOOSEN THE 2 SCREWS ON THE CONTROLLER COUNTERCLOCKWISE


TOOL: HEX KEY 3MM



REMOVE THE WET END

LOOSEN THE 8 SCREWS ON THE BACK SIDE OF THE SEAL PLATE

TOOL: HEX KEY 5MM



| REMOVE THE PUMP BODY

**HIT THE MOTOR BASE WITH A HAMMER
TO HELP REMOVE THE PUMP BODY**


TOOL: RUBBER HAMMER



REMOVE THE VOLUTE

LOOSEN THE 3 SCREWS ON THE VOLUTE AND REMOVE THE O-RING ON THE VOLUTE


TOOL: SCREW DRIVER PH5



| REMOVE THE IMPELLER

REMOVE THE TURNABLE RING, IMPELLER NUT, AND SPRING WASHER ON THE IMPELLER

TOOL: T-TYPE SOCKET WRENCH 17MM




REMOVE THE IMPELLER

**TAKE OFF THE IMPELLER AND THE SHAFT KEY
FROM THE MOTOR SHAFT**



REMOVE THE IMPELLER

REMOVE THE O-RING ON THE IMPELLER



| REMOVE THE O-RING


REMOVE THE 3 O-RINGS ON THE SEAL PLATE



| REMOVE THE PRESSURE SENSOR

**LOOSE THE 4 SCREWS ON THE COVER PLATE,
REMOVE THE COVER PLATE & SEALING GASKET**


TOOL: SCREW DRIVER PH2



| REMOVE THE PRESSURE SENSOR

REMOVE THE GLUE & UNPLUG THE RED CONNECTION ; LOOSEN THE PRESSURE SENSOR



TOOL: CUTTER KNIFE & SPANNER 22MM



REMOVE THE MOTOR

LOOSEN THE 4 SCREWS ON THE MOTOR SEPARATE THE MOTOR AND THE SEAL PLATE

TOOL: HEX KEY 5.5MM





ASSEMBLY

THE GRAPHITE SIDE OF THE STATIONARY & ROTATING RING OF THE MECHANICAL SEAL SHOULD FACE OUTWARD



ASSEMBLY


**THE KEYWAY AT THE IMPELLER SHOULD BE
ALIGNED WITH THE SHAFTKEY WHEN ASSEMBLY**



ASSEMBLY

LARGER SIDE OF THE TURNABLE RING FACES
UPWARD

SCREW LENGTHS ARE DIFFERENT ON THE VOLUTE



ASSEMBLY

INSTALL THE RUBBER PLUG INSIDE THE PUMP BODY

