

# USER MANUAL MODULAR AIR COOLED WATER CHILLER AND HEAT PUMP



AMH-Series AMH68D-MO2 AMH90D-MO2 AMH136D-MO2 R410A 400-50Hz-3PH

# 1. Foreword:

Thank you for choosing us. Please read the manual carefully before you install and use our products. We preserve the rights to change the contents of this manual. We shall not be responsible for the loss and failure caused in the process of installation due to not conforming to this manual.

# 2. Introduction

Air cooled water chillers, which is a new generation of modular units developed by our company. This unit is energy-saving and convenient in use, which has the function of reverse cycle automatic defrosting, two-stage automatic anti-freezing, built-in self-diagnose able system, and is controlled by microcomputer. It can be widely used to hotels, villas, hospitals, cinemas, stadiums, recreations, office blocks, factories and so on. It can also provide industrial cooled water and hypo thermal water for the technical manufacture.

The unit is suit for installing in out space such as roof, floor and porch, left off the boiler room and the special room, decreased the investment of building project. And without cooling water system such as cooling tower and cooling pump, this unit saves the water greatly. And the unit is easy to install, manage and maintain.

## **Characteristic and merits**

## 2.1.Modular design

This series of Air cooled water chiller use the concept of modular design, This series of Air cooled water chiller and heat pump unit use the concept of modular design, whose basic modular units are heat pump(cooling only)60kw or 68kw.The basic modular unit can operates alone, or 1-7 basic modular units can be assembled to an integrated unit according to the needed capacity, expending the selecting range of cooling capacity from 60kw to 490kw. It is convenient for transporting and loading due to its compact structure, small size and light weight. Each modular unit is divided to two independent cooling systems, convenient to maintain. And with a high flexibility, it is convenient to adjust and control the energy and expand the capacity.

## 2.2.Fully-automatic control

The operation and management of this unit are controlled by microcomputer system. It is easy to operate so that the professional management personnel are unnecessary. The units turn on/off the compressor automatically according to the load, making the units operate on the point of the most economical, and saved the energy. And there are complete protect functions such as error self-detect system, balancing the compressor wear automatically, and anti-freezing automatically in winter.

## 2.3.Appearance

The air cooled condenser can be placed in "V" or "U" type, which is ingenious, beautiful and compact. This unit looks clear and refinement by means of designing the components and tubs reasonably. The cover is coated by electrostatic powder, making the color even and unvarying. And the color can be chosen by the customer, who can also use the stainless steel plate. The unit is well in anti-corrosion, so that it can be placed in outdoor space without special room.

## 2.4. Intelligent defrosting

Each modular is separate to the others at inner cooling system, and controls the operation of the system independently. So it is separating at start-up. According to the different climatic conditions (temperature and humidity) to set the parameters for automatic defrosting, defrosting is thoroughly and energy-saving, increasing the heating efficiency. And the defrosting has no significant influence to the indoor air-conditioning temperature.

## 2.5.Intelligent anti-freezing

This unit adopts dual-class automatic anti-freezing protection, preventing the water system be damaged once the water froze at winter. The anti-freezing protection can be quite automatically when the water temperature is increased according to the operation of heating mode or water pump.

## 2.6.Convenient operation

Each unit is strictly detected before delivered. The refrigerant and cooing oil are injected.

And the protective parameters are set. So you will just connect the power and the water pipes at installation, and operate the computer controller when you use it.

# 3. Equipment installation

## 3.1.Preparation

3.1.1.Check the units carefully referring to packing list after the units transported to installation site.

Please inform the Sales Department if there is any damage to the unit in transportation.

3.1.2.Customers supply armor plate or concrete foundation, the size of foundation refers to the size of four orientation hotels of unit, the foundation can adopt frame structure, with the frame on girder or pole, ensure that frame can support 150% times of weight of unit and a solid level foundation.

3.1.3.Customer use crane vehicle for easy transportation, crane vehicle intensity must be three times of unit weight, and forbidden any person under the unit.

And with proper partition supporting things to protect the top and side board of the unit (above drawing). Keep a horizontal level in transportation.



## 3.1.4.Installation site

Modular units can be installed on the outside ground, ceiling and other proper site. Note the following factors:

1) Keep unit from defoliation, insects or other places easy for accumulation, preventing obstruct heat exchanger.

2) Adjust the direction of air-side heat exchanger in installation, in case of the strong sunlight.

3) Leave barrel-drain surrounding heat pump, to discharge defrost condensation water.

4) Leave 1.5m on each side for ventilation and maintenance.



5) If there are wall around unit, the all should not higher than unit, and leave 2.4m from the wall. Leave 3-3.5m or above on the top, in case of air return.



6) If there is wall higher than unit at one side, leave 1.8m from the wall.



7) Add rubber dampers of 10-20mm between the unit and base.

8) Fix the the unit with suitable bolt.

3.1.5.Base

1)The foundation can be made of cement or steel plate, but it must be able to fully withstand the weight during operation, and the level should be within 3/1000.

2)In order to avoid the joint twisted or broken because of the distortion caused by earthquake, typhoon or long-term operation of the equipment, the unit should take proper fixing measures.

3)When the unit is installed on the roof or balcony, special attention should be paid to whether the floor strength can withstand the weight during operation.

4) The foundation of the unit must be solid to minimize vibration transmission.

5)The unit should be equipped with shock absorbers to prevent noise and vibration transmission and reduce vibration to the unit.

6)When setting the base, the floor must be preset with a drain pipe to drain the water in the water pipe or equipment.

7)Drawing:



		AMH								
		60/68/90	120/136/180	180/210/270	240/280/360	300/350/450	360/408/540			
1	n	1	2	3	4	5	6			
A B C	Ą	1350	2880	4410	5940	7470	9000			
	3	1030	1030	1030	1030	1030	1030			
	)	/	450	450	450	450	450			

## 60/68/90 dimension of base

136 dimension of base

	AMH								
	136	272	408	544	680	816	952		
n	1	2	3	4	5	6	7		
A	2400	4980	7560	10140	12720	15300	17880		
В	2130	2130	2130	2130	2130	2130	2130		
C		450	450	450	450	450	450		

## 3.2. Attention

## In design and construction water supply system, please note that:

3.2.1.Choose proper water pump for water supplying system to ensure the difference between actual water supply amount and unit acquiring water supply amount is less than 10%.

3.2.2.Please do add a water filter before the water inlet pipe, and please select filters have 40 holes/inch at least.

3.2.3.Install expansion tank on the water return pipe, in case of the water volume change due to temperature. The expansion tank should be 1-1.5m higher than the top of the system; the volume should be about 1/10 of the system volume; and there must have heat preservation measures for chilled water pipe and expansion valve.

3.2.4.Install water flow switch on water outlet pipe (paddle flow meter), avoid of damage to unit due to lack of water

3.2.5. Air discharge valve tapis designed in the highest point of water system.

3.2.6.Install water discharge tap or valve in the lowest point of water system.

3.2.7. Water pipe must be heat preservation, preventing heat loss or condensation.

3.2.8.System pipe installation, according to country and local heat criterion. Adopting anti-shake flexible joint for unit and linking system, and place supporter for pipe and pump. Forbid turning on check valve of inlet and outlet opening before washing pipe clean .

3.2.9.Cooled water system



## Pay attention to connecting electric wire :

1) Wire connecting means electricity supply wire and communication control wire. For customers: Don't change the control wire in the electric control box.

2) Connecting electric wire referring to the following table: (cooling only unit and heat pump are the same)

Note: unit controller is along with unit, in construction, it can be put in the main module, or in customer's controller room, controller connecting line is 1000m at most. (need specified transformer).

Module	Wire section, mm <sup>2</sup>						
Qty	1	2	3	4	5	6	7
60	3*10+2*6	3*25+2*10	3*50+2*16	3*70+2*25	3*120+2*50	3*150+2*70	3*185+2*90
68	3*10+2*6	3*25+2*10	3*50+2*16	3*70+2*25	3*120+2*50	3*150+2*70	3*185+2*90
90	3*16+2*10	3*50+2*25	3*95+2*50	3*150+2*70	3*185+2*95	3*240+2*120	3*300+2*150
136	3*25+2*16	3*70+2*35	3*150+2*70	3*240+2*120	3*300+2*150	3*400+2*185	3*500+2*240

## 4. Equipment maintenance

## 4.1. Daily maintenance

4.1.1.Keep the equipment clean.

4.1.2. Check every component for loose or damage.

4.1.3.Check the leaks of refrigerant, check if the value of refrigerant gauge is 0 or less than normal value. Check if there is leaks of refrigerant or oil on the pipe or component connection with the suds or refrigerant leakage detector.

4.1.4.Check external chain circuit, water flow switch as well as water temperature, water pressure and water flow is normal or not, already exhaust completely or not.

4.1.5. Check the power supply is normal or not before power on and power off.

4.1.6.Check if there is any abnormal shake or noise.

4.1.7. Check the high/low pressure whether normal after power on.

4.1.8. Check the equipment start, stop and temperature control whether normal after power on.

4.1.9.Record the running condition, voltage, electric current, high/low pressure, inlet/outlet water temperature and so on.

4.1.10. Inform professionals to maintain if there is any abnormal condition.

## 4.2. Season maintenance

4.2.1.Check the insulation resistance of compressor with tramegger or Electrical safety performance testing instrument.

4.2.2. Cut off power supply, clean power circuit and switch and contacts of control system.

4.2.3. Check the water, water pipe whether normal, clean water pipe in necessity.

4.2.4. Check and clean shell and tube heat exchanger, check whether there is dust or sundries on

the fins exchanger, ensure good heat dissipation.

## 4.3. Annual maintenance

4.3.1. Check the protection switch of equipment and running situation, adjust in necessity.

4.3.2. Clean heat exchanger and controlling parts in control box.

## 4.4. In cold area, discharge all water in the shell and tube exchanger, avoid damage caused by frozen.

## 5. Equipment repair

#### 5.1.Failure of refrigerant system.

5.1.1. Recover refrigerant: Cannot discharge refrigerant in fins or tube-tube heat exchanger too rapidly, if too rapidly, it will absorb heat and make the water temperature decline and appear freeze, shall keep water pump running and water flowing when discharge, to avoid the damage of copper tube caused by water frozen.

5.1.2. Dismount

<1> Shall avoid sundries and dust enter the pipe and part after dismounted, cannot place in air long time, otherwise will be oxidized, so shall seal or cover; if need to place for long time, shall seal the opening of relevant pipe, compressor, vacuumize and charging nitrogen.

<2> Shall keep clean when repair, avoid sundries and dust enter refrigerant system.

<3> Clean the parts with the same refrigerant oil with used for compressor.

5.1.3. Gas-tight test: After reassembled unit after repaired.

<1> Pressure test

A. Add little refrigerant into refrigerant pipe, then charging nitrogen (Pressure shall less than 20kg/cm<sup>2</sup>).

B. Cannot use oxygen or acetylene as pressurized gas, to avoid bomb, shall use pressure regulating valve when charging nitrogen, adjust to the needed pressure and then pressurized, must move away the nitrogen cylinder after pressurized.

C. Pressure test time shall be depend on the real situation, check whether the pressure decline, then check the leak preliminary.

<2> Leak detection: use leak detector or soapy water.

5.1.4.Vacuumize

<1> The purpose of vacuumize is to eliminate the water in the system.

<2> Discharge the air in the system firstly before vacuumize.

<3> Higher vacuum degree is better, system vacuum degree shall  $\leq$ 5mmHg.

5.1.5.Charging refrigerant

<1> Supplement system refrigerant.

A. Start compressor

B. Charging gaseous refrigerant at low pressure side, not charging too much one time, shall gradually charging with little quantity.

C. Check the running situation, check the high/low pressure, superheat/supercool degree and high pressure exhaust temperature.

D. Stop refrigerant charging when unit running normally.

<2> Re-supplement system refrigerant.

- A. Charging gaseous refrigerant at high pressure side.
- B. Charging quantity shall near to the quantity of original system.
- C. Check refrigerant pressure is normal or not.
- D. Start compressor.

E. Charging gaseous refrigerant at low pressure side, not charging too much one time, shall gradually charging with little quantity.

F. Check the running situation, check the high/low pressure, superheat/supercool degree and high pressure exhaust temperature.

G. Stop refrigerant charging when unit running normally.

How to judge whether the refrigerant is excess or insufficient: Usually, high pressure will be rise when excess, super cool degree will be bigger, super heat degree will be smaller, split out temperature will be low; high pressure will be lower when insufficient, super cool degree wil be smaller, super heat degree will be bigger, split out temperature will be rise.

## 5.2. Failure of electrical control system.

5.2.1. Inspect according to electric diagram.

5.2.2. Shut off power supply, meanwhile, connect the control power supply and check the control circuit.

5.2.3. Pay attention to safety and avoid electrical shock

## 5.3. Check water system

5.3.1. When there is failure at water system, shall stop compressor.

5.3.2. Avoid water hammer when stop water pump, especially when there is no check valve on water system, shall slowly close stop valve at outlet side of water pump, then stop water pump.

5.3.3. Close valves after water pump stopped.

5.3.4. Repair after water draining.

5.3.5. After repaired, open relevant valves, open discharge valve first after start water pump, discharge the air in the water pipe.

## 5.4. Failure and countermeasure

Failure	Confirm	Reason	Countermeasure
	Fuse is normal in safe box	The main power switch cutoff. Incorrect voltage Incorrect phase	Check and confirm normal.
tart	Fuse is burn in safe box	Control wiring is hort out or ground connect	Clear failture and change fuse
Compressor not s	Electromagnetic contactor not work	<ol> <li>1.Electromagnetic contactor breakdown.</li> <li>2. Water flow switch not work</li> <li>3. Water temp. is too low.</li> <li>4. Protection switch act.</li> <li>1. Bad wiring connection</li> </ol>	<ol> <li>Repare and change</li> <li>Check water pump and water flow switch.</li> <li>Unit back to normal when water temp. Up.</li> <li>Clear fault</li> <li>Check connection and lock screw</li> </ol>
	Electromagnetic contactor is normal.	<ol> <li>Compressor lock</li> <li>Motor burn up</li> </ol>	2. Change compressor
Shut down	Cold water control act	Cold water temp. was set too high or loading too little.	Adjust setting or increase loading.
once start	Overload relay act	<ol> <li>Cold water temp. Is too high</li> <li>Over-current was set too low.</li> </ol>	<ol> <li>Adjust water temperature</li> <li>Adjust over-current.</li> </ol>
	High pressure switch act	<ol> <li>Condenser air flow insufficient</li> <li>Condenser coil is too dirty</li> <li>Refrigerant was charged too much.</li> <li>Inlet cold water is too high.</li> </ol>	<ol> <li>Increase air flow or check the fan</li> <li>Clean condenser coil.</li> <li>Adjust refrigerant.</li> <li>Reduce load.</li> </ol>
Shut down after start	Low pressure switch act	<ol> <li>Cooling water temperature was set too low or load is too little.</li> <li>Cooling water is insufficient.</li> <li>Expansion valve is bad.</li> <li>Filter was blocked.</li> <li>Refrigerant is leak.</li> </ol>	<ol> <li>Adjust setting or increase load.</li> <li>Increase water flow.</li> <li>Change expansion valve.</li> <li>Clean filter.</li> <li>Clear fault and charging refrigerant.</li> </ol>
	Overheat protection switch act.	<ol> <li>Overheat temperature is too high.</li> <li>Refrigerant is leak,</li> <li>Motor bearing or coil is bad</li> </ol>	<ol> <li>Insufficient refrigerant adjust overheat</li> <li>Clear fault and charging refrigerant.</li> <li>Change compressor.</li> </ol>
	Anti-freezing control act	Cooling water is too little	Increase water flow
Not cooling	Cooling water temperature is too high	<ol> <li>Loading is too much, chiller capacity is not enough.</li> <li>Chiller system is not good.</li> </ol>	<ol> <li>Add chiller quantity.</li> <li>Clear fault.</li> </ol>
	Cooling water temperature is too low.	<ol> <li>Cooling water flow is insufficient</li> <li>Terminal units is bad</li> </ol>	<ol> <li>Add water flow</li> <li>Repair terminal units</li> </ol>
Abnormal shock and noise	-	<ol> <li>Compressor is not good</li> <li>Expansion valve is not good</li> <li>Base is not strong enough.</li> <li>Water pipe shock together</li> </ol>	<ol> <li>Check and repair compressor</li> <li>Adjust expansion valve</li> <li>Reinforce the base</li> <li>Enhance the quake-proof</li> </ol>

# 6. Electrical control instructions

## 6.1 Interface to panel

6.1.1 Introduction to panel



# 6.1.2 Overview of interface Key switching

Five physical keys: ON/OFF, function, up, down, enter



Note: 1. in branch interface (excluded count down interface and main interface), if no key action within one minute, the system will return to the main interface automatically.

2. When " $\blacktriangle$ " is displayed on the right of the interface, it indicates that the <up> can be pressed under the page to perform page up.

3. When " $\mathbf{\nabla}$ " is displayed on the right of the interface, it indicates that the <down> can be pressed under the page to perform page down.

4. When the interface prompts "no operation now, operate after XX seconds", it indicates that operation is performed on other interfaces. Please wait for.

Operation may be made on the screen after XX seconds.

## 6.1.3 Word and icon

<1>. Explanation to word

- ① Operation status: Indicate the current operation status of the unit including operation and shutdown.
- ② Operation mode: Indicate the current operation mode of the unit including refrigeration, heating and automatic, etc.
- ③ Unit status: Indicate the current operation state of the unit including anti-freezing, defrosting and preheating, etc.
- (4) One Chinese character position: indicate occupying 16\*16 dot matrix of position on LCD display.

- ⑤ One character position: Indicate occupying 8\*16 dot matrix of position on LCD display.
- 6 Physical keys: indicate the actual keys corresponding on hardware.
- ⑦ Key function: indicate the actual meaning of physical keys. A physical key may corresponding to many key functions.
- <2>. Description of icon

lcon	Meaning	Remark
SET *C	Indicating temperature setting	
4	Indicating page up, parameter selection, increasing value.	
D	Indicating page down, parameter selection, decreasing value.	
G	Indicating that whether the unit uses timing function.	
Fn	Indicating the icon of functional keys and only used for menu, cancellation, return and shift.	
æ	Indicating the icon of confirming keys and only used for enter, confirmation, noise reduction, reset and switching module.	
Ū	Indicating the icon of ON/OFF and only used for starting/shutting down the unit.	
UFn △ ▼#	Indicating to slide from left to right to unlock keys.	

#### 6.1.4 Breakdown of interface

#### <1>. Overview

DM603A products have five keys, one 128\*64 LCD display without indicator light in the front,

According to the actual use process, it is divided into: main interface, state inquiry interface, parameter setting interface and fault inquiry interface.

<2>. Interface switching



## 6.1.5 Starting-up interface

The starting up interface includes count down interface and main interface after completion of count down.

<1> Countdown interface



The above interface is normal starting-up interface of the unit when there is no fault. If other interfaces appear when starting up, please refer to <u>8. Troubleshooting</u>

Note: ① In the countdown interface at starting up, press <up> or <down> to switch language directly. ②The concrete function code and version number should be subject to actual product.

<2> Main interface



Description:

[1] Represent prompt of interface with locked keys and mean that the current interface is locked.

[2] Current operation mode of the unit: if "operation mode" = refrigeration,, then display refrigeration, When "operation mode" = heating, then display heating

When "operation mode" = automatic, then display automatic

Press the <up> or <down> keys or press <enter> key to switch to change the value of the mode.

[3] The current control temperature of the unit: When "control object" = return temperature, then display the return temperature of the system.

When "operation mode" = outlet temperature, then display outlet temperature of the system.

When—is displayed, it indicates probe fault or the measurement value exceeds the range.

Press the <up> or <down> keys to change the temperature value directly.

[4] Indicates the current status on the unit: display that the unit is at anti-freezing, defrosting or preheating state or the operation status of the unit.

The timing status of the unit: if there is timing icon, it indicates the timing function.

If there is no timing icon, it indicates no timing function.

[5] fault inquiry of the unit: When the unit has fault, it will prompts <enter> key to enter fault inquiry. When the unit does not have fault, it will display the system clock directly.

## 6.1.6 Status inquiry

<1>Fault inquiry

When fault occurs to the main interface, press <enter> key to enter current fault inquiry.



#### **Description:**

[1] Indicate the fault code of the current fault inquired in fault type and the corresponding fault information, please refer to the instruction book of control panel for concrete fault code. Press <up> or <down> key to switch display of fault module or fault number:  $FF# \rightarrow$  system fault;  $00#~15# \rightarrow$  module fault; the module number 00~15 corresponds to the module address setting of 0 to F of SR1 on control panel.

[2] Indicates to press <Function> key to return to menu of previous level.

【3】 Indicates to press <Enter> key to reset fault. Indicate to return to the main interface if there is no fault at present. If there is any fault, it continues to display the current fault.

[4] Indicate there is no fault after pressing <enter> key. Then it returns to the main interface.

#### <2>Status inquiry

After entering the status inquiry interface, press <enter> key to switch module status inquiry.



#### **Description:**

【1】 Press <enter> key to switch among different module interfaces. In the interface, the status of all modules of the unit may be inquired. The module number is subject to the actual number of modules. The last item is the system module and indicates the system status. Others correspond to 00~15 # modules and indicate the module status.

[2] Indicates to return to the interface of previous level by pressing <function> key.

【3】 Display the operation status of output equipment corresponding to modules. Inverse display: indicate that the equipment is outputting at present. As shown in the figure, 1# compressor, 1# four-way valve and 2# compressor of 00# module have output. Normal display indicates no output such as 2# four-way valve.

[4] Display the analog quantity signal of corresponding system module.

[5] Display the analog quantity information of corresponding 00# module.

#### <3>Clock inquiry

After entering the status inquiry interface, press <down>or<up> to select clock inquiry.



V.	
<b>V</b> 11	121

Description:

[1] Press <function> key to select year, month, day, hour, minute and seconds in order.

[2] Indicates to return to the interface of previous level by pressing <enter> key.

[3] In the interface, press <function> key to select year, month, day, hour, minute and seconds in order. And press <+> or <-> to set the value.

Press <enter> key to save the setting and exit from the setting.

#### <4>Version inquiry

After entering the status inquiry interface, press <down>or<up> to select version inquiry.



Description:

- [1] Indicate the version and function code corresponding to display screen. Press <down> to continue the inquiry.
- [2] Indicate the version and function code corresponding to control. Press <up> to continue the inquiry.
- [3] Indicates to press <function> key to return to menu of previous level.

<5>Timing set

Press <down> or <up> to select timing set.



Description:

- [1] indicates to change the timing item by pressing <enter> key.
- [2] indicates to confirm the changed timing value by pressing <function> key
- [3] indicate the selection of setting of timing
- [4] indicate the selection of primary timing
- [5] indicate to select 01 group timing. Press <up> or <down> to switch among use of timing, primary timing and setting from 01 group to 10# group. After entering the selected timing item, press <enter> key to change the

set timing on/off, hour and minute, week  $(1, 2 \cdots 7)$ ; when week is selected, the corresponding will flask); Press <up> or <down> key to change the selected value. Inverse display of week  $(1, 2 \cdots 7)$  indicates that timing is effective on the day. As shown in the figure, shutdown will be performed at 23:00 on Friday and Saturday. Note: if the time of timing is 00:00, it indicates the function is not used.

## 6.1.7 Password operation

#### <1>Password input



Description:

[1] Remind the users to input password including repair and manufacturer password.

[2] Press <enter> key to confirm the input password and enter parameter setting.

[3] Indicates to press <function> key to shift the input password at present. Press up or down to input the current password value.

[4] Indicates to press <enter> key to input password again.

[5] Indicates to return to the interface of previous level by pressing <function> key.

#### <2>Password change



Description:

[1] Remind the users to input the old password including repair and manufacturer password respectively. Different passwords may be changed at different levels.

[2] Press <enter> key to confirm the input to change the password. If change is correct, successful change is prompted. Failure is prompted for wrong change.

[3] Indicates to return to the interface of previous level by pressing <function> key.

Note: if the old password is input wrong, then it prompt wrong input of old password.

if the new password is input wrong, then it prompt wrong input of new password.

#### 6.1.8 Parameter setting

1. Operation of the section is suitable for setting of all parameters.

2. For parameter setting of repair setting and manufacturer setting, the parameters visible are different only due to password levels. But the setting method is the same.

3. All settings have corresponding password change. Please refer to <u>4.2 password change</u>.

4. The initialization of parameter and initialization of operation time of compressor are only provided in manufacturer parameter setting and are not set in other settings.

#### <1> Parameter level

Please refer to <u>4.1 password input operation</u> for input of password.

· ·									
	Function	Кеу	Effective interface of key	Password					
	Advanced function	<function></function>		User password					
	Repair setting	<entor eunstion=""  =""></entor>	Main interface	Repair password					
	Manufacturer setting			Manufacturer password					
	Maintenance setting	<enter +="" function=""></enter>	Countdown interface	Maintenance password					

#### <2> Parameter setting



Description:

[1] Indicates to enter the parameter setting item and determine the content of changed parameter by pressing <enter> key.

[2] Indicates to press <function> key to cancel the changed parameter value and return to the interface of previous level.

[3] Indicate the name of parameter group. The major item "PL01 user parameter 1" is displayed by prompt here.

"01 control mode" represents character string corresponding to the sub item; press <up> or <down> key to switch among sub-item of parameters in the parameter group circularly.

Press <up> or <down> key to make change directly and press <enter> to save the value of current parameter. If the parameter value is not accessible.

[4] Indicates that the selected parameter is bit variable. It means that all sub-items of the parameter is operated according to bit.

If the parameter is variable, it will be divided into 16 sub-items for operation.

In addition, "PL02-01 module use" indicates the character string of sub-item of 01 switching value that corresponds to the PL02 major item.

[5] Indicate to switch all corresponding sub-items in the major item of parameter by pressing <enter> key. If it is bit variable, switch the corresponding bit item.

## <3>Initialization

After entering manufacturer setting, press <down> or <up> to select the corresponding content for initialization. Initialize parameter: the parameters are restored to default value.

Initialize compressor: the operation time of compressor and accumulate operation time of the unit is 0.

The operation of initialization of parameter and compressor is the same. The initialization process is introduced with initialization of parameter as an example.



Description:

[1] Initialize the operation parameter of the unit, with the operation character of initialization is prompted.

[2] When the prompt of "initialization failed" appears, If it failed, initialization may be performed according to above operation until success is prompted.

[3] Indicate to return to the interface of previous level by pressing <function> key.

# Attention:

If the unit is at the operation or alarm state, parameter cannot be initialized or parameter initialization failed may be prompted.

After parameter initialization of the unit is successful, ensure to power on the unit again and use after confirm that the parameters are in effective.

## 6.1.9.Advanced function

Advanced functions include: user setting---mode setting and temperature setting

Manual defrost---module defrosting setting

Password change---user password setting

Module use setting---use setting for all modules of the unit

Inquiry of operation time---inquiry of operation time

Inquiry of historical fault--- Inquiry of historical fault

The following provides detailed description for all operation. Please refer to parameter setting and password operation for operation of other interfaces.

#### <1>Manual defrost

Enter general setting and press <down> or <up> and select manual defrost.



Description:

[1] In the interface, press <up> or <down> to select the module in the unit that needs defrosting. Then press <enter> to send order of manual defrost.

[2] Indicate to save and return to the interface of previous level by pressing <function> key.

[3] Indicate that the current mode is under forced defrosting.

[4] Indicate to press <up> or <down> to switch among modules under forced defrosting.

#### <2>Inquiry of operation time

After entering the status inquiry interface, press <down>or<up> to select operation time inquiry.



Description:

**(1)** Press <enter> key to select different module interfaces. In the interface, you can inquire the operation time of all modules of the unit. The module number is subject to the actual number of modules. The last item is the system module and indicates the system status. Others correspond to 00~15 # modules and indicate the module status.

[2] Indicate to return to the interface of previous level by pressing <function> key.

[3] In the interface, the operation time of all compressor in use may be inquired. The above figure indicates that the operation time of 1# and 2# compressors of 00# module in the unit is 0 hour.

Display the accumulated operation time of the unit.

#### <3>Inquiry of historical fault

After entering the status inquiry interface, press <down>or<up> to select inquiry of historical fault.



Description:

[1] Time of fault occurrence: Indicate the time of fault occurrence.

Press <enter> key to clear all historical faults.

[2] Indicate the fault type displayed currently: press <module> to switch the display of module with fault; FF# $\rightarrow$  system fault; 00#~15# $\rightarrow$  module fault, the module number 00~15 corresponds to the module address setting of 0 to F of SR1 on control panel.

[3] Indicate to return to the menu of previous level by pressing <function> key.

#### 6.1.10 System maintenance setting

During the process of countdown for starting up, after pressing <enter + function> to input the password for system maintenance setting, enter the interface of system maintenance setting.



Description:

[1] Press <enter>+<function> to enter system maintenance interface in the interface of countdown for starting up.

【2】 Indicate to inquire the current operation time of the unit. It is used for reference of users and cannot be changed. System maintenance days setting can be set. 0 days indicates that system maintenance setting is not enabled. X days indicates that system maintenance will be performed in X days after setting is made. The scope of X is: 0~1365 days.

[3] Press <enter> key to select the parameter to be changed.

[4] Return to the interface of previous level by pressing <function> key.

[5] Press <down> key to select system initialization, accumulated operation time and system maintenance setting. After initialization, the accumulated operation time of the system is cleared to zero. The system maintenance setting is restored to the default value 0 day.

## 6.1.11 Troubleshooting

Name	Problem interface	Description	Solution
System maintenance prompt: unable to start normally if maintenance is not made in time. Please contact the manufacturer as soon as possible.	Maintenance is made after 168 hours. The machine cannot start without timely maintenance	If the interface appears, please refer to description of "system maintenance prompt" in instruction book for control panel.	Return to the main interface pressing <enter> key. Refer to relevant content of instruction book for control panel for disposal.</enter>
In maintenance: Maintenance of category A. Please contact with the manufacturer.	In maintenance of category A. Please contact with the manufacturer.	After the completion of countdown of starting up, if the maintenance time of the system is due, the system will stay at the interface and other normal operation cannot be performed.	Refer to relevant content of instruction book for control panel for disposal.
Module or system malfunctions.	00#: 37# malfunctions Power fault	If fault occurs after starting, the monitor gives out alarm.	Refer to relevant description for troubleshooting of control panel.

## 6.2. Operating description

#### 6.2.1 Start and shutdown

There are three methods to start and shut down the unit:

<1>ON/OFF key (start key and stop key) on display screen

<2>Remote switch

[Remote switch type PL03-09]=toggle switch: the unit starts when the remote switch is connected. Stop the unit when it is disconnected.

[**Remote switch type PL03-09**]=pulse switch: effective when the remote switch is connected->disconnected (pulse width >300ms).

If it is under the shutdown state, start the unit. Stop the unit if it is under operation.

<3>Start/shutdown by alarm: start or shut down the machine according to the set time. Refer to [time alarm set] in instruction for use

The priority is the same for three modes.

#### 6.2.2 Description of fault reset

4 types of reset method for fault:

- <1> Power on reset
- After the fault is removed, the reset cannot be performed unless powering on again.
- Fault requiring for power on reset: wrong EEPROM data.

<2> Limited automatic reset

- Alarm after removal of fault, time delay **[fault reset time PL08-03]**; the same fault doesn't occur within the time. Reset automatically.
- Within the set time **[permissible time for automatic reset PL08-04]**, it may reset twice automatically. If the accumulated alarm time is >2, manual reset is required. After manual reset, the alarm times may be accumulated again.
- Limited fault: refer to the fault table.

<3> Automatic reset:

• Alarm after removal of fault, time delay [fault reset time PL08-03]; the same fault doesn't occur within the time.

Reset automatically.

- No limit for times of automatic reset:;
- Fault with automatic reset: refer to the fault table.

<4> Manual reset:

- If alarm is given after fault is removed, manual reset is conducted only through the controller.
- Manual reset may also be made for fault of category 1), 2) and 3).

## 6.3 System maintenance

## 6.3.1Introduction to function

The controller is provided with function of system maintenance. It is used to limit the operation time of the unit. When the maintenance time of the system is due, the unit is stopped forcedly. It should not start again before system maintenance is canceled. The anti-freezing function is not affected during the period of system maintenance. "System maintenance" function is disabled at default.

"Accumulated operation time of the unit" is calculated with hour as unit. It is converted into "day" at the time of calculating "maintenance time of the system" (note: it is **operation time/24 hours and not the actual days).** 

The system maintenance and setting interface permits operation of 3 items, as shown in the following table (please refer

Item	Name	Setting	Default	Unit	Remark		
number	Name	range	value	Onit			
00	Inquiry of accumulated	/	/	Day			
	operation time of the						
	unit						
01	System maintenance	01365	0	Day	Setting as 0 indicates that the function is		
	time setting				disabled.		
02	Initialization of system	/	/	/	Initialize "accumulated operation time of the		
	maintenance time				unit" and the set value of "system maintenance		
					time".		

to instruction book of display for description of concrete operation and interface).

## 6.3.2 System maintenance prompt

When the "system maintenance" function is set as enabled, the function of system maintenance prompt is provided to avoid inconvenience brought to users caused by sudden forced shutdown.

When the remaining operation time of the unit is > 168 hours (7 days), the unit operates normally and no reminding is given. When the remaining operation time of the unit is  $\leq$ 168 hours (7 days), the prompt rule is as follows.

- The unit is powered on again;
- The time of timed prompt is due. (The time of timed prompt is different due to different monitors. Please refer to the instruction book of monitor for details. )

When one of two above conditions is met, the remaining operation time is reminded. Please refer to the instruction book for prompt interface.

## 6.3.3 Examples

For example: if **[system maintenance time setting 01]** is three days, **[Inquiry of accumulated operation time of the unit 00]** is 0 day.

"Accumulated operation time of the unit" starts timing after the unit operates and stops timing after the units stops.

When the accumulated operation time of the unit is < 24 hours, the result of **[Inquiry of accumulated operation time of the unit 00]** is 0 (day).

When 24 hours  $\leq$  the accumulated operation time of the unit< 48 hours, the result of **[Inquiry of accumulated operation time of the unit 00]** is 1 (day).

When 48 hours  $\leq$  the accumulated operation time of the unit< 72 hours, the result of **[Inquiry of accumulated operation time of the unit 00]** is 2 (day).

And so on.

When the accumulated operation time of the unit is  $\geq$ 72 hours, **[Inquiry of accumulated operation time of the unit 00]** reaches **3** days, the system maintenance time is due. The unit stops forcedly and cannot operate unless system maintenance is canceled.

## 6.4 Password management

The controller is provided with two types of password at present. They are independent from each other.

1) Use of deadline password: used to enter setting of service life.

The initial value at factory: \*\*\*\*\*\*\*\*.

2) Parameter setting password: used to enter setting of all parameters:

Parameter setting password is divided into four levels, including:

Manufacturer password: initial value of factory:\*\*\*\*\*\* (Operate all parameters)

Repair password: initial value of factory: \*\*\*\*\*

User password: initial value of factory:\*\*\*

Refer to the parameter setting table of machine for parameters operated by passwords at all levels. Wherein, the manufacturer password has highest priority, the user password has lowest priority. The priority is arranged according to sequence. The password at high priority can enter the operation level at low priority and change the password.

Note:

(1) Re-download of program or parameter initialization will not change or initialize the original password.

(2) Password may be set again, but cannot be initialized.

(3) When the password is set, at the step of "input of old password", the password at the current level may be input and the password at higher level may also be input.

#### 6.5 Parameter management

1) After parameter initialization is made for main module, the slave module will be initialized synchronously.

2) Parameters may be set for slave module separately, but it is only effective at the state without power down. After powering on again, the parameter of slave module will update to be identical with those of the main module.

# Appendix 1: fault table

Appendix 1.1 Description of fault detection

- Reset mode: A = automatic reset; M=manual reset; AM=limited automatic reset; refer to [description of fault reset].
- For fault of the following switching values, if there is no special description, alarm is given after [time delay for general fault PL08-01] elimination of shaking
- For fault of the following sensors, if there is no special description, alarm is given after elimination of shaking of 4 seconds.

Failure R		Detection condition	Alarm operation	Troubleshooting		
Fault of controller						
Wrong EEPROM data	Power on reset	Detection after powering on	If the fault is serious, stop the unit.	<ol> <li>Initialize all parameters</li> <li>If the fault is not removed after initialization, please contact us!</li> </ol>		
Fault of the unit						
Overload of air conditioner water pump	м	Detect after the air conditioner water pump starts,	If the fault is serious, stop the unit.	Check the state of input J11-7 and see whether it is consistent with the setting of [Overload of air conditioner water pump PL13-01.01].		
Insufficient flowrate of air condition water	cient flowrate of air on water M Detect after time delay after the air conditioner pump starts, Refer to description of <b>[protection of</b> <b>insufficient water flow].</b> The main module gives alarm and stop the corresponding module.		Check the state of input J11-8 and see whether it is consistent with the setting of [insufficient water flow of air conditioner PL13-01.01].			
Overload of hot water pump	м	Detection after powering on		Check the state of input J12-3 and see whether it is consistent with the setting of [Overload of hot water pump PL14-01.15].		
Insufficient hot water flow	М	Detect after time delay after the hot water pump starts, Refer to description of <b>[protection of</b> <b>insufficient water flow].</b>	Stop operation of hot water pump	Check the state of input J12-9 and see whether it is consistent with the setting of [Insufficient hot water flow PL14-01.09].		
Power fault	М	Detect after powering on; refer to description of [power protection].	Refer to description of [power protection]	<ul> <li>Check the detection J2 for phase error and phase default of three-phase power supply and whether the connection is normal.</li> <li>Check whether the power fault input is consist with setting of switching values.</li> </ul>		

Communication fault	М	Detection after powering on	Stop corresponding module	<ol> <li>Check whether the communication lines among main modules behind the monitor are connected normally and contact well.</li> <li>Check whether the communication lines among modules are connected normally and contact well.</li> </ol>	
High pressure/overload of compressor	М	Detect after time delay after the compressor starts, Refer to description of [high pressure protection]		Check whether the overload input of compressor is consist with setting of switching values.	
Low pressure of compressor	A/M	Detect after time delay after the compressor starts, Refer to description of [low pressure protection]	Stop corresponding compressors an fans	Check whether the low pressure input of fan is consist with setting of switching values.	
Overload of condensate fan	oad of condensate fan M Detection after powering on			Check whether the fan overload input is consist with setting of switching values.	
Low outlet temperature of air conditioner	A	<ol> <li>Refer to description of [outlet water temperature protection of the system].</li> </ol>	<ol> <li>Outlet water protection of the system</li> <li>Stop operation of all modules, only</li> </ol>	Check whether the value of outlet water temperature meets [parameter of air conditioner outlet water [PL08-09]~ [PL08-11]	
High outlet temperature of air conditioner		<ol> <li>Refer to description of [outlet water temperature protection of module].</li> </ol>	<ol> <li>Outlet water protection of module. Stop operation of the module.</li> </ol>	Check whether the value of outlet water temperature meets [high outlet temperature of air conditioner of heating PL08-11].	
High fin temperature	A/M	Refer to description of [outlet water temperature protection of module].	Stop corresponding compressors an fans	Check whether the value of fin temperature meets [Protection of high fin temperature PL08-12].	
Anti-icing protection	A	Detect when refrigeration operates and at the non anti-freezing state.	Stop all compressors of the unit	Check whether the value of anti-freezing temperature meets [ <b>Protection of high fin temperature</b> PL08-18].	

Fault of sensor								
Fault of probe for outlet								
water temperature of the								
system			Stop the unit					
Fault of probe for return			(Anti-freezing operation is handled					
water temperature of the			separately; refer to description of	1	Charle whether the weeks is severe stad			
system			[anti-freezing logic].	1.	Check whether the probe is connected			
Environmental temperature	N.4	Detection ofter new oring on		2	Normally. Check [DI 15 use setting of temperature			
probe fault	171	Detection after powering on		۷.	probal and soo whathar the proba that is			
Fault of proba for outlot			Stop operation of the module.		probel and see whether the probe that is			
water temperature			(If the evaporator is independent, stop		not connected is out of use.			
			the corresponding compressor).					
Temperature probe fault of			Stop corresponding compressors on fans					
fin			Stop corresponding compressors an fairs					
Fault of anti-icing probe			Stop all compressors of the unit					

## Appendix 1.2 inquiry of fault code FF system fault

Decimal system	Fault name	Remark	Decimal system	Fault name	Remark
0	Communication fault		33	Environmental temperature probe fault	
1	Power fault	Power fault on main module	34	Fault of probe for outlet temperature of the system	
2	Wrong EEPROM data		35	Fault of probe for return temperature of the system	
8	Overload of air conditioner pump		36	Fault of probe for hot water temperature of the system	
9	Insufficient flow rate of air condition water	Insufficient water flow of main module	40	High outlet water temperature of the system	
10	Overload of hot water pump		41	Low outlet water temperature of the system	
11	Insufficient hot water flow				
14					
15					

Decimal	Fault name	Remark	
/18	Low pressure of #1 compressor	nemark	
40	High pressure /overload of #1 compressor	Relevant fault of compressor 1	
4J 55	Temperature probe fault of #1 fin		
57	low current of 1# compressor		
58	High temperature of 1# fin		
60	High current of 1# compressor		
61	Anti-freezing high pressure protection of 1# compressor	_	
80	I ow pressure of #2 compressor		
<u>81</u>	High pressure /overload of #2 compressor	4	
87	Temperature probe fault of 2# fin	4	
80	Low current of 2# compressor	Bolovant fault of compressor 2	
00	High tomporature of 2#fin		
90	High current of 2# compressor		
92	Apti fragzing high prossure protection of 2# compressor	4	
112	Anti-freezing flight pressure protection of 2# compressor		
112	Low pressure of #3 compressor	-	
115	Tomporature probe fault of 2# fin	4	
119	Low surrent of 2# compressor	Relevant fault of compressor 3	
121	Low current of 5# compressor		
122	High current of 2# compressor	-	
124	Anti fragzing high processor	_	
144	Anti-freezing fight pressure protection of 5# compressor		
144		_	
145	Tomporature probe fault of 4# fin	Relevant fault of compressor 4	
151			
153	Low current of 4# compressor		
154		_	
150	Anti fragzing high processor	_	
157	Anti-freezing high pressure protection of 4# compressor		
170	Power Iduit	_	
1/0	Foult of insufficient water flow of the unit	_	
182	Fault of insufficient water now of the unit	_	
185	Overload of fan 1	Unit fault	
180	Overload of fan 2		
187	Overload of fan 3		
188	Overload of fan 4		
192	Fault of 1# probe for evaporation and outlet temperature		
194	Fault of 3# probe for evaporation and outlet temperature		
196	High outlet temperature of 1# air conditioner		
200	Low outlet temperature of 1# air conditioner		
244	Fault of anti-icing probe	_	
245	Anti-icing protection		